

Elcometer Blast Hose Quick Couplings



Designed for increased safety and a prolonged lifespan, the Elcometer **Blast Hose Quick Couplings** securely attach to the end of the blast hose creating a solid connection and a consistent flow.

Cast Iron Quick Hose Coupling

Elcometer cast iron quick hose couplings are supplied with safety clips, gasket and coupling screws and are ideal for use up to 15bar (174psi) working pressure.

Part Numbers

Part Number	For Blast Hose Internal Diameter (ID)	For Blast Hose Outside Diameter (OD)	Elcometer Blast Hose
SQC-13	13mm (½")	28mm (1⅛")	BH13
SQC-25	25mm (1")	38mm (1½")	BH25
SQC-32	32mm (1¼")	48mm (1⅞")	BH32 & BH32X
SQC-32L	32mm (1¼")	48mm (1⅞")	BH32 & BH32X
SQC-38	38mm (1½")	55mm (2⅜")	BH38 & BH38X

Nylon¹ Quick Hose Coupling

Elcometer nylon quick hose couplings are supplied with springlock safety clips, gasket and coupling screws. Nylon hose couplings are not recommended for use above 12bar (174 psi) working pressure.

Part Numbers

Part Number	For Blast Hose Internal Diameter (ID)	For Blast Hose Outside Diameter (OD)	Elcometer Blast Hose
NQC-19²	19mm (¾")	34mm (1⅜")	BH19
NQC-25²	25mm (1")	38mm (1½")	BH25
NQC-32³	32mm (1¼")	48mm (1⅞")	BH32 & BH32X
NQC-38³	38mm (1½")	56mm (2⅜")	BH38 & BH38X

Spare Parts

Part Number	Description
MT28723	Coupling Screws (x10) - for BH13 Nozzle Holders and Quick Hose Couplings
MT28724	Coupling Screws (x10) - for BH19+ Nozzle Holder and Quick Hose Couplings
MT29495-2	Gasket (x5) - for SQC-25+ Quick Hose Coupling
MT29495-1	Gasket (x5) - for SQC-13 Quick Hose Coupling
MT29495-5	Gasket (x5) - for NQC-19 Quick Hose Coupling
MT29495-4	Gasket (x5) - for NQC-25 Quick Hose Coupling
MT29495-3	Gasket (x5) - for NQC-32 & NQC-38 Quick Hose Coupling
MT28890	Replacement Cast Iron Coupling Safety Clip (x10)
MT27880	Replacement Nylon Coupling Safety Clip (x10)



Replacement Nylon Coupling Safety Clip



Replacement Cast Iron Coupling Safety Clip

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://elcometer.nt-rt.ru/> || erj@nt-rt.ru